

OpenSpace™ Pro Software



Overview

The OpenSpace parking solution also includes the OpenSpace™ Pro software package. This utility allows you to set the times of sign operation, number of available spots, reset or adjust the counter, and get statistics related to garage occupancy. OpenSpace™ Pro comes pre-loaded on a Windows tablet or laptop that connects directly to the OpenSpace VMS via Bluetooth. It can be optionally loaded on a laptop or nearby desktop computer to allow you to configure and control the sign.

Features

OpenSpace Pro allows you to:

- Control what motorists are able to see on the sign.
- Set and adjust the number of available spaces in your facility.
- Configure the operating parameters for the sign.
- Set the operating schedule for the sign.
- Generate statistics related to garage occupancy.
- Download reports to excel

OpenSpace Pro Software



OpenSpace Speed Hump



OpenSpace VMS



Options

- Operating System: Microsoft Windows 7 or later
- Screen Resolution: 1024 x 600 pixels
- Communication Interface: Bluetooth (Class 1 adapter supplied)
- Disk Space: TBD



Weekly Maximum Occupancy Report
 Location: **Test Site**
 February 02, 2015 to February 08, 2015

Time	Monday, %	Tuesday, %	Wednesday, %	Thursday, %	Friday, %	MAX, %	MIN, %	AVG, %
00:00	1	0	0	1	0	1	0	0
01:00	1	0	0	1	0	1	0	0
02:00	1	1	0	1	0	1	0	1
03:00	1	0	0	1	0	1	0	1
04:00	1	1	0	1	0	1	0	1
05:00	3	2	2	2	2	3	0	2
06:00	12	10	9	9	12	12	2	10
07:00	30	30	28	28	30	30	9	30
08:00	60	58	58	58	60	60	28	58
09:00	77	73	72	70	74	77	58	74
10:00	81	78	78	74	77	81	71	78

Generate Weekly Statistics Reports

Standard Reports Available

- Daily/Weekly Occupancy
- 2-Day Occupancy Comparison
- Weekly Turnover
- Daily/Weekly Ingress
- Daily/Weekly Egress
- Daily Ingress Comparison

System Requirements

- Operating System: Microsoft Windows 7 or later
- Screen Resolution: 1024 x 600 pixels
- Communication Interface: Bluetooth (Class 1 adapter supplied)
- Disk Space: TBD

